

How To Set The Time:

1. Remove clock from the mount using your fingernail.
2. Locate the crown, 3 o'clock for non-EL and 6 o'clock for the EL.
3. Gently pull crown out and twist to set to correct time. When done gently push crown in to lock.
4. Replace clock back into mount. Seat into mount until no gasket material can be seen.

Battery Replacement:

Your clock is a quality timepiece; we recommend battery replacement always be performed by a professional.

If you have any questions, please remember, complete customer service is ALWAYS available through www.clocks4bikes.com.

Care and Mounting Instructions



3 Year Warranty (Even If You Loose It)

Clocks4Bikes

632 Stokes Road • Flora, MS 39071

Toll Free: 866-856-5825

www.clocks4bikes.com

ross@clocks4bikes.com

Mounting Instructions:

Dash Mount-- Use double-sided 3M tape (provided) or stainless steel screw (provided) to secure clock mount.

Stick-on Mount-- Mount these on any flat, clean surface with double-sided 3M tape (provided).

Fairing Mounts for FSLT-- Use double-sided 3M tape (provided) to secure mounts to fairing dash plugs. Removal of dash plugs is not required. Align clock and thermometer inserts straight in the mounts.

Victory Shock Tube Mounts-- Remove the caps on ends of the shock tubes. Replace with our clock and thermometer friction-fit mounts. Align clock and thermometer inserts straight in the mounts.

BMW R1200C Stem Plug Mount-- Remove stem bolt cover. Insert clock mount using original BMW O-ring. Align clock or thermometer straight in the mount.

Handlebar Mounts-- The mount fits over a straight section of handlebar like a saddle. Tilt the mount for best viewing angle. Tighten the set screw with the allen wrench provided.

Stem mounts-- Fit the mount over the stock nut down on the triple tree. Tighten the set screw along one of the straight sections of the nut. The clock/thermometer insert can be taken out of the mount and realigned if necessary.

Dyna/Sportster-- Unscrew stem bolt cover (see stem mount instructions above)/

Harley Big Boy Mount- Heritage Softail, Fatboy, Deluxe, Superglide, Wideglide
-- Unscrew the chrome cover on the triple tree with your hand or rubber strap wrench. Install mount using a phillips screwdriver. Insert the clock or thermometer into the mount.

Harley Road King Lock Clock-- Remove the cover that reads lock/unlock with your fingers. Remove the two screws with a phillips screwdriver. Install our clock using the screws provided. Align the clock straight in the mount.